


FMC234

Vehicle Tracker

Installation manual



Vehicle Tracker overview.

FMC234 with 1000 mAh high-capacity battery, ensures prolonged autonomous usage, when external power is lost or disconnected. It comes equipped with internal GNSS, LTE antennas, 3 configurable digital inputs/outputs, Bluetooth® connectivity. FMC234 can be used in a variety of vehicles, such as lifts, cars, tractors, trailers etc.

Popular accessories.



RFID reader TQ407

RFID reader for Mifare tags. Has an internal buzzer and LED. See page 7 for specific installation scheme.



RFID reader NP18-X36 and X43

RFID reader for Mifare tags, X43 has support for EM tags aswell. Has an internal buzzer and LED. See page 8 for specific installation scheme.



Temperature sensor

1-wire temperature sensor. Up to 4 sensors can be connected in parallel. See page 9 for specific installation scheme.

Need help with the installation?

Chat with us.

The easiest way to contact us is through the built in chat function in the app. Just press the “Quick menu” at the bottom of your screen and select “Support”.

Send us an email.

For less urgent matters, please email us at support@infabricfleet.se.

FMC234 wiring diagram.

| Wire color | Pin name | Description | Mandatory |
|---------------------|------------------------|---|-----------|
| 1 Red | VCC (10-30) VDC (+) | Power supply (10-30 V DC) | Yes |
| 2 Gray | DOUT 3 | Digital output, channel 3. Open collector output. Max 0,5 A DC | No |
| 3 White | DIN 3 | Digital input, channel 3 | No |
| 4 White/ Green | DIN 2 | Digital input, channel 2. This will count the production hours, if applicable | No |
| 5 Yellow | DIN 1 | Digital input, channel 1. Connect to ignition signal. This signal will count the engine running hours. | Yes |
| 6 White/Blue | INPUT 6 | TX EXT | No |
| 7 Black | GND (-) | Ground pin. (10-30) V DC (-) | Yes |
| 8 White/ Orange | DOUT 1 | Digital output, channel 1. Open collector output. Max 0,5 A DC. | No |
| 9 Purple | DOUT 2 | Digital output, channel 2. Open collector output. Max 0,5 A DC. This is used for the Machine Access feature. Connect this to a relay that controls the machine's immobilizer. When the signal is high, the machine will be operational. This output can also be used for enabling buzzer and LED when using a RFID reader | No |
| 10 Blue | 1WIRE POWER | +3,8 V output for 1-Wire devices | No |
| 11 Green | 1WIRE DATA | Data for 1-Wire devices | No |
| 12 White/ Yellow | INPUT 5 | RX EXT | No |

FMC234 data sheet.


| Specifications | |
|--------------------------------------|--|
| Dimensions | 70,5 x 67 x 25,6 mm (L x W x H) |
| GNSS | GPS, GLONASS, GALILEO, BEIDOU, QZSS, AGPS |
| Position accuracy | < 2.5 CEP |
| Cellular technology | LTE Cat 1, GSM |
| Input voltage range | 10-30 V DC with overvoltage protection |
| Internal back-up battery | 1000 mAh Li-Po rechargeable |
| Internal fuse | 3 A, 125 V |
| Power consumption | At 12V <5 mA (Deep Sleep) At 12V <16 mA (Online Deep Sleep) At 12V <33 mA (nominal with no load) At 12V <2 A (full load/peak) |
| Operating temperature (with battery) | -20 C to +60 C |
| Operating humidity | 5% to 95% non-condensing |
| Ingress Protection Rating | IP67 |
| Digital inputs | 3 |
| Digital outputs | 3 |
| 1-Wire | 1 |
| GNSS antenna | Internal High Gain |
| Cellular antenna | Internal High Gain |
| Memory | 128MB internal flash memory |
| Bluetooth | 4.0 + BLE |

Get started!

1. Download the app


Download Infabric Fleet app from [App Store](#) or [Google Play](#). Login and follow the configuration wizard of the vehicle and device.

2. Choose your harness and installation options



Standard harness

12-wire open-end harness, used for connecting inputs and outputs. An external 3A fuse is required (mandatory, not included). This installation must be performed by a trained installer.



Easy harness

Used for a simple installation directly on the vehicle battery. When you do not need any extra input to the device.


3. Follow the installation scheme, based on your needs

If the app information is not enough for your needs, look at the examples of installation schemes to find more inspiration.


4. Verify the installation

This is the most important step, to make sure that you have done the installation correct and that all expected data is present. The verification is done in the app.

Basic installation.




RFID reader TQ407.



| Vehicle Tracker | RFID reader TQ407 | Description |
|-----------------|-------------------|--|
| Red | - | Connect to the positive side of the battery (+) |
| Black | Black | Connect to the negative side of the battery (-) |
| Yellow | Yellow | Connect to the vehicle's ignition signal |
| Purple | Blue and Red | Buzzer and LED. Both the blue and red wires from the RFID reader should be connected to the purple wire on the Vehicle Tracker |
| Green | White | 1-Wire DATA |

RFID reader NP18-X36 and X43.




| Vehicle Tracker | RFID reader NP18-X36 and X43 | Description |
|-----------------|------------------------------|--|
| Red | - | Connect to the positive side of the battery (+) |
| Black | Yellow | Connect to the negative side of the battery (-) |
| Yellow | Green | Connect to the vehicle's ignition signal |
| Purple | White and Gray | Buzzer and LED. Both the white and gray wires from the RFID reader should be connected to the purple wire on the Vehicle Tracker |
| Green | Brown | 1-Wire DATA |

Temperature sensor.


Note:

- Up to 4 temperature sensors can be connected in parallel.



| Vehicle Tracker | Temperature sensor | Description |
|-----------------|--------------------|---|
| Red | - | Connect to the positive side of the battery (+) |
| Black | Brown | Connect to the negative side of the battery (-) |
| Yellow | - | Connect to the vehicle's ignition signal |
| Blue | Green | 1-Wire POWER |
| Green | White | 1-Wire DATA |

Private button AR-271.




| Vehicle Tracker | Private button AR-271 | Description |
|-----------------|-----------------------|---|
| Red | Red | Connect to the positive side of the battery (+) |
| Black | Black | Connect to the negative side of the battery (-) |
| Yellow | - | Connect to the vehicle's ignition signal |
| White/Green | Orange | Button and LED |

Machine Access with an Internal Combustion Engine machine.

Note:


- We strongly recommend disabling only a specific function, such as raising the lift, so that the operator can still move the machine in case of an emergency.
- The relay is not included. Choose a relay based on the vehicle's operating voltage, typically either 12V or 24V.
- The relay installation may vary depending on the specific signal required for the intended function.



Machine Access with an Electric/Battery driven machine.

Note:

- We strongly recommend disabling only a specific function, such as raising the lift, so that the operator can still move the machine in case of an emergency.
- Since many electric lifts/machines are often left with the ignition signal on, we recommend connecting the ignition/yellow wire to the electric motor signal instead.
- The relay is not included. Choose a relay based on the vehicle's operating voltage, typically either 12V or 24V.
- The relay installation may vary depending on the specific signal required for the intended function.



Verify your installation.

- It is very important that you verify your installation before you leave the vehicle.
- Make sure to test all the connected inputs and outputs as well as any connected accessory.
- If a main switch is used, make sure that the connected inputs show the correct state both when the main switch is on and off.
- When using a main switch on the ground (negative) side, the device must be wired in series with the switch. If not, the connected inputs may report false or incorrect states while the main switch is off.
- Ensure that both LEDs are blinking every second, as this indicates the device has good reception. If the LEDs are not blinking as expected, move the vehicle outdoors and ensure the device has a clear line of sight to the sky, unobstructed by any metal objects.
- Check all functionality of the vehicle, such as engine starting, any dashboard messages etc.
- Use the included double sided adhesive tape to fasten the device in the vehicle. Make sure all cables are fastened.

LED indication.

| Status LED | Meaning |
|--------------------------------|------------------------------------|
| Blinking every second | Normal mode |
| Blinking every two seconds | Sleep mode |
| Blinking fast for a short time | Modem activity |
| Off | Boot mode or device is not working |

| Navigate LED | Meaning |
|-----------------------|--------------------------------------|
| Blinking every second | Normal mode, GNSS signal is received |
| Permanently on | GNSS signal is not received |
| Blinking fast | Device firmware is being updated |
| Off | Sleep mode or device is not working |